


ADAPTRONIC
- engine management -

M1200 22 Pin Connector Wiring Diagram



Wire Colors Note:
B - Black Br - Brown G - Green Gy - Grey
L - Blue O - Orange P - Pink R - Red
V - Violet Y - Yellow W - White
If wire has two colors and is shown with a slash, eg [B/R], it means black with a red trace.

Note:
1. Pins with red text are optional.

CAUTION:
DO NOT CONNECT IGNITION OUTPUTS DIRECTLY TO IGNITION COILS


The ECU has no built-in igniter. A separate ignitor or transistor must be used. Damaging the ECU outputs via misconnection will void warranty.

Title
M1200 22 Pin Connector Wiring Diagram

Size	Number	Revision
A4		
Date:	8-Jun-2017	Sheet of
File:	Z:\Products\Modular\looms\M1200	Drawn By:

ADAPTRONIC
- engine management -

M1200 26 Pin Connector Wiring Diagram



Title
M1200 26 Pin Connector Wiring Diagram

Size	Number	Revision
A4		
Date:	7-Jun-2017	Sheet of
File:	Z:\Products\Modular\looms\M1200	Drawn By: